



INSTALLATION INSTRUCTIONS

Accessory
THIRD ROW SEAT COVERS
P/N 08P32-TK8-100A

Application
2011 ODYSSEY

Publications No.
All 43901
Issue Date
SEP 2010


Put this information in the glove box with the vehicle owner's manual.

PARTS LIST


2 Third row headrest covers



Left third row seat back cover



Left third row seat cushion cover



Center third row headrest cover




Right third row seat back cover



Right third row seat cushion cover



Illustration of the Third Row Seat Covers Installed on the Vehicle




INSTALLATION

Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."

NOTE:


- Be careful not to damage the seats while installing the rear seat covers.
- Do not install the third row seat covers to the front seats. Improperly covering the front seat can prevent your side airbags from inflating in a side impact.
- Identify each third row seat cover by the tags on the back.

1. Fold the third row seats forward halfway.




2. Push the knob and remove each headrest from the third row seats.


3. Install the two third row headrest covers and center third row headrest cover to three headrests as shown.



4. Install the left third row seat back cover to the left third row seat back with three hook-and-loop fasteners. Install in the order 1 → 2 → 3 → 4. NOTE: Make sure that the headrest guide on the left third row seat is not covered by the left third row seat back cover.





5. Fold down the left third row seat. Secure the left third row seat back cover to the left third row seat back with one hook-and-loop fastener. Return the left third row seat to its standard position.



6. Install the left third row seat cushion cover to the left third row seat cushion in the order **1** → **2** → **3**.

LEFT THIRD ROW SEAT CUSHION COVER




LEFT THIRD ROW SEAT CUSHION

LEFT THIRD ROW SEAT CUSHION COVER

2 HOOKS

7. Secure the left third row seat cushion cover to the left third row seat cushion with the two hook-and-loop fasteners.



LEFT THIRD ROW SEAT CUSHION COVER


LEFT THIRD ROW SEAT CUSHION

2 HOOK-AND-LOOP FASTENERS

8. Install the right third row seat back cover to the right third row seat back with the two hook-and-loop fasteners. Install in the order **1** → **2** → **3** → **4**. NOTE: Make sure that headrest guide on the right third row seat is not covered by the right third row seat back cover.

2 HOOK-AND-LOOP FASTENERS


HEADREST GUIDE
Do not cover.



RIGHT THIRD ROW SEAT BACK COVER

RIGHT THIRD ROW SEAT BACK

9. Fold down the right third row seat. Secure the right third row seat back cover to the right third row seat back with one hook-and-loop fastener. Return the right third row seat to its standard position.




RIGHT THIRD ROW SEAT BACK COVER


RIGHT THIRD ROW SEAT BACK

HOOK-AND-LOOP FASTENER

10. Install the right third row seat cushion cover to the right third row seat cushion in the order **1** → **2** → **3**.



11. Secure the right third row seat cushion cover to the right third row seat cushion with the two hook-and-loop fasteners.



12. Reinstall each headrest.